



A+

# PRESTIGE POOLS & SPAS



## How to Manually Vacuum Your In Ground Pool

### Components:

Vac Head



Vac Hose



Skim Vac Adaptor



Vac Pole



1. Attach vac head to vac pole, vac hose to vac head (swivel end of vac hose must be attached to vac head).
2. Attach skim vac adaptor to skimmer basket.
3. Place end of vac hose in front of the return jet to prime your vac hose (ridding it of all air that may cause suction issues).
4. Attach vac hose to skim vac adaptor.
5. Close all other skimmers, leaving only the skimmer in use and the main drain open.
6. To regulate suction, close main drain half way. If suction is still not great enough, close off the drain completely. If suction is too great, open main drain up completely to alleviate pressure.

After you are done, clean out your filter system out completely and reopen any closed plumbing lines.